

MAINTENANCE :

The rope body of your Bent Oak Rocker is hand woven. If the weave of the rope body is pulled out of shape, you can brush or adjust it into shape with your hands. The wood frame should be periodically refinished using a high quality polyurethane varnish. When refinishing the wood, you have two options. First, you can remove the small wooden strips on the front and back of the chair, slide the rope body to one side, and apply varnish. After the finish has dried, slide the ropes to the other side and repeat. If you want to completely remove the ropes, take the following steps to keep the seat from coming unwoven.

Before removing the ropes from the wooden bars, slide guide ropes through the topmost and bottommost row of loops, and tie them off.

You can now safely remove all nuts and bolts from the wood using a 7/16 ratchet and key. Once all hardware is removed and safely stored, sand the wood using 120-grit sandpaper. You can use any shade of marine-grade polyurethane. We originally applied three coats of high-gloss varnish, but two coats should be sufficient. In between coats, lightly re-sand the wood pieces with 220-grit sandpaper after the wood has air-dried for 24 hours. Refinishing is the perfect time to also replace the nuts, bolts, washers, and screws, all readily available at your local hardware store.

To wash the rope seat, you can either leave the ropes attached to the chair or remove them. **If you remove the ropes, make sure you follow the instructions above to keep your seat from unravelling.** You will need OxiClean or laundry detergent and a soft scrub brush. To begin cleaning, wet the rope and apply the detergent. Additionally, you may use a very mild bleach solution, but be sure to rinse the ropes thoroughly afterwards. Take a handful of rope in each hand and rub the pieces together; using the soft-bristled scrub brush to work on any stains. Once you've cleaned all of the rope, rinse it thoroughly. If you have removed the rope from the chair, arrange it on a flat surface to air-dry so that the rope does not stretch.

If you have any questions about maintaining your chair, please give us a call at 1-800-344-6433 or 252-441-6115

WARRANTY AND RETURNS :

Nags Head Hammocks products are guaranteed to be free of defects in both workmanship and material. Prolonged exposure to weather conditions including snow, rain, and humidity are not covered under the warranty, nor is damage caused by normal wear, mildew, or improper care, including storage, maintenance, and assembly. If you are not satisfied with an item, return it unused in its original packaging for a complete refund or exchange. You can return it to any of our stores or to our warehouse, Nags Head Hammocks, 305 Industrial Blvd., Greenville, NC 27834. Please include a copy of your receipt and your contact information.

Instruction #: 5083NH-5131NH, 0G.11




SINGLE OR DOUBLE BENT OAK ROCKER



Congratulations! You now own a Bent Oak Rocker that was handcrafted in North Carolina by Nags Head Hammocks. We hope you will have many years of comfort and enjoyment. If you have any questions, please feel free to contact us. Relax! It's a Nags Head Hammock original.

P.O. Box 533
Nags Head, NC 27959
1-800-344-6433 • 252-441-6115
www.nagshead.com

PARTS LIST :

 <p>3 Loose Bars</p>	
 <p>2 Arm/Runner Units</p>	 <p>1 Roll-Up : Note: The “top” bar of the roll-up features a thin wooden strip with brass tacks. The “bottom” bar has a thicker wooden strip attached with screws.</p>
<p>1 Hardware Pack:</p> <ul style="list-style-type: none"> (1) Instruction Sheet (4) 3” Carriage Bolts (6) 2.5” Carriage Bolts (10) Washers (10) Hex Nuts 	<p>Tips for Assembly :</p> <p>Tip 1: Do not tighten bolts completely until fully assembled</p> <p>Tip 2: For a more uniform look, face all bolts in the same direction</p>
<p>You Will Need : One 7/16” wrench and a mallet or hammer</p>	

ASSEMBLY :

Step 1 : Set arm units on the floor 2 feet apart (4 feet apart for the double rocker). If sitting in the chair, the branded arm unit should be on your right hand side.

Step 2 : Attach a loose bar to the back of the runners with two 3” carriage bolts. Attach another loose bar to the front with two more 3” carriage bolts.

Step 3 : Attach the remaining loose bar to the inside of the arms (behind the arm rests) using the two 2.5” carriage bolts.

Step 4 : To attach the roll-up, take the “top bar” of the roll-up (the bar with brass tacks) and attach it to the top of the chair with 2.5” carriage bolts.

Step 5 : Attach the “bottom” bar of the roll-up (the bar with screws) to the front of the arm unit using 2.5” carriage bolts.

Step 6 : Tighten all nuts.

DIAGRAM :

